


---

# CLUTCH

	Page
TROUBLESHOOTING .....	CL-2
CHECK AND ADJUSTMENT OF CLUTCH PEDAL ....	CL-3
BLEEDING OF CLUTCH SYSTEM .....	CL-4
INSPECTION OF CLUTCH START SYSTEM .....	CL-4
CLUTCH MASTER CYLINDER .....	CL-6
CLUTCH RELEASE CYLINDER .....	CL-8
CLUTCH UNIT .....	CL-11

## TROUBLESHOOTING

Problem	Possible cause	Remedy	Page
Hard to shift or will not shift	Clutch pedal freeplay excessive	Adjust pedal freeplay	CL-3
	Air in clutch lines	Bleed clutch system	CL-4
	Clutch release cylinder faulty	Repair release cylinder	CL-8
	Clutch master cylinder faulty	Repair master cylinder	CL-6
	Clutch disc out of true, runout is excessive or lining broken	Inspect clutch disc	CL-11
	Splines on input shaft or clutch disc dirty or burred	Repair as necessary	CL-11
	Clutch pressure plate faulty	Replace clutch cover	CL-11
Transmission jumps out of gear	Clutch pilot bearing worn	Replace pilot bearing	CL-11
Clutch slips	Clutch pedal freeplay insufficient	Adjust pedal freeplay	CL-3
	Clutch disc lining oily or worn out	Inspect clutch disc	CL-11
	Pressure plate faulty	Replace clutch cover	CL-11
	Release fork binding	Inspect release fork	CL-11
Clutch grabs/ chatters	Clutch disc lining oily or worn out	Inspect clutch disc	CL-11
	Pressure plate faulty	Replace clutch cover	CL-11
	Clutch diaphragm spring bent	Align clutch diaphragm	CL-11
	Engine mounts loose	Repair as necessary	
Clutch pedal spongy	Air in clutch lines	Bleed clutch system	CL-4
	Clutch release cylinder faulty	Repair release cylinder	CL-8
	Clutch master cylinder faulty	Repair master cylinder	CL-6
Clutch noisy	Loose part inside housing	Repair as necessary	
	Release bearing worn or dirty	Replace release bearing	CL-11
	Pilot bearing worn	Replace pilot bearing	CL-11



## CHECK AND ADJUSTMENT OF CLUTCH PEDAL

### 1. CHECK THAT PEDAL HEIGHT IS CORRECT

Pedal height from asphalt sheet: 157 – 167 mm  
(6.18 – 6.57 in.)

### 2. IF NECESSARY, ADJUST PEDAL HEIGHT

- (a) Loosen the lock nut and turn the adjusting bolt until the height is correct.
- (b) Tighten the lock nut.
- (c) After adjusting the pedal height, check the pedal freeplay.

### 3. CHECK THAT PEDAL FREEPLAY IS CORRECT AS SPECIFIED

Push in on the pedal until the beginning of clutch resistance is felt.

**Pedal freeplay: 5 – 15 mm (0.20 – 0.59 in.)**

**Push rod play at pedal: 1 – 5 mm (0.04 – 0.20 in.)**

### 4. IF NECESSARY, ADJUST PEDAL FREEPLAY

- (a) Loosen the lock nut and turn the push rod until the freeplay is correct.
- (b) Tighten the lock nut.
- (c) After adjusting the pedal freeplay, check the pedal height.

### 5. CHECK PEDAL OPERATION

While gently depressing the pedal, check that engagement and disengagement are smooth.


### 6. INSPECT CLUTCH RELEASE POINT

- (a) Pull the parking brake lever and install wheel stopper.
- (b) Start the engine and idle the engine.
- (c) Without depressing the clutch pedal, slowly shift the shift lever into reverse position until the gears contact.
- (d) Gradually depress the clutch pedal and measure the stroke distance from the point the gear noise stops (release point) up to the full stroke end position.

**Standard distance: 25 mm (0.98 in.) or more**  
**(From pedal stroke end position to release point)**

If clearance is not as specified, perform the following operation.

- Inspect pedal height.
- Inspect push rod play and pedal free play.
- Bleed the clutch line.
- Inspect the clutch cover and disc.



## BLEEDING OF CLUTCH SYSTEM

**HINT:** If any work is done on the clutch system or if air is suspected in the clutch lines, bleed the system of air.

**NOTICE:** Do not let brake fluid remain on a painted surface. Wash it off immediately.

### 1. FILL CLUTCH RESERVOIR WITH BRAKE FLUID

Check the reservoir frequently. Add fluid if necessary.



### 2. CONNECT VINYL TUBE TO BLEEDER PLUG

Insert the other end of the tube in a half-full container of brake fluid.

### 3. BLEED CLUTCH LINE

- (a) Slowly pump the clutch pedal several times.
- (b) While depressing the pedal, loosen the bleeder plug until the fluid starts to run out. Then close the bleeder plug.
- (c) Repeat this procedure until there are no bubbles in the fluid.

**HINT:** Do not reuse the fluid that was bled. It contains air.



## INSPECTION OF CLUTCH START SYSTEM

### CHECK CLUTCH PEDAL


1. CHECK THAT PEDAL HEIGHT IS CORRECT  
(See page CL-3)
2. CHECK THAT PEDAL FREEPLAY AND PUSH ROD PLAY ARE CORRECT  
(See page CL-3)

### CHECK CLUTCH START SYSTEM

#### CHECK CLUTCH START SYSTEM

- (a) Check that the engine does not start when the clutch pedal is released.
- (b) Check that the engine starts when the clutch pedal is fully depressed.
- (c) Check that clearance "A" is greater than 1 mm (0.04 in.) when the clutch pedal is fully depressed.

If necessary, adjust or replace the clutch start switch.




### INSPECTION AND ADJUSTMENT OF CLUTCH START SWITCH

#### 1. INSPECT CONTINUITY OF CLUTCH START SWITCH


- (a) Check that there is continuity between terminals when the switch is ON (pushed).
- (b) Check that there is no continuity between terminals when the switch is OFF (free).

If continuity is not as specified, replace the switch.





**2. ADJUST CLUTCH START SWITCH**

- (a) Measure the pedal stroke, and check the switch clearance "A" using the chart left.
- (b) Loosen and adjust the switch position.




- (c) Recheck that the engine does not start when the clutch pedal is released.

# CLUTCH MASTER CYLINDER COMPONENTS




## REMOVAL OF MASTER CYLINDER

1. DRAW OUT FLUID WITH SYRINGE
2. DISCONNECT CLUTCH LINE UNION  
Using SST, disconnect the union nut.  
SST 09751-36011
3. REMOVE INSTRUMENT LOWER FINISH PANEL AND AIR DUCT
4. REMOVE CLIP, CLEVIS PIN AND SPRING WASHER
5. REMOVE MOUNTING NUTS AND PULL OUT MASTER CYLINDER



## DISASSEMBLY OF MASTER CYLINDER

1. REMOVE RESERVOIR TANK  
Remove the hold-down bolt and pull off the reservoir tank.
2. REMOVE PUSH ROD
  - (a) Pull back the boot, and using a screwdriver, remove the snap ring.
  - (b) Pull out the push rod assembly.
3. REMOVE PISTON  
Using compressed air, remove the piston from the cylinder.



**INSPECTION OF MASTER CYLINDER**

HINT: Clean the disassembled parts with compressed air.

**1. INSPECT MASTER CYLINDER BORE FOR SCORING OR CORROSION**


If a problem is found, clean or replace the cylinder.

**2. INSPECT PISTON AND CUPS FOR WEAR, SCORING, CRACKS OR SWELLING**

If either one requires replacement, use the parts from the cylinder kit.

**3. INSPECT PUSH ROD FOR WEAR OR DAMAGE**

If necessary, replace the push rod.

**ASSEMBLY OF MASTER CYLINDER**

(See page CL-6)


**1. COAT PARTS WITH LITHIUM SOAP BASE GLYCOL GREASE, AS SHOWN**

**2. INSERT PISTON INTO CYLINDER**

**3. INSTALL PUSH ROD ASSEMBLY WITH SNAP RING**

**4. INSTALL RESERVOIR TANK**

Torque: 250 kg-cm (18 ft-lb, 25 N·m)

**INSTALLATION OF MASTER CYLINDER**

(See page CL-6)

**1. POSITION MASTER CYLINDER AND CONNECT CLUTCH LINE UNION**

First finger-tighten the union nut and then tighten it to specified torque with SST.

SST 09751-36011

Torque: 155 kg-cm (11 ft-lb, 15 N·m)

**2. INSTALL AND TIGHTEN MOUNTING NUTS**

**3. INSTALL PUSH ROD ASSEMBLY TO CLUTCH PEDAL**

Secure the clevis pin with the spring washer and clip.

**4. BLEED CLUTCH SYSTEM**


(See page CL-4)

**5. CHECK FOR LEAKS**



**6. CHECK AND ADJUST CLUTCH PEDAL**

(See page CL-3)

**7. INSTALL INSTRUMENT LOWER FINISH PANEL AND AIR DUCT**



# CLUTCH RELEASE CYLINDER COMPONENTS



## REMOVAL OF RELEASE CYLINDER


(7M-GE)

### 1. REMOVE FLEXIBLE HOSE


(a) Using SST, disconnect the union.

SST 09751-36011

(b) Remove the flexible hose from the release cylinder.








CL0215

## 2. REMOVE RELEASE CYLINDER

Remove the two bolts and pull out the release cylinder.




CL0311

### (7M-GTE)

## 1. REMOVE CLUTCH LINE TUBE

Using SST, disconnect the two union nuts and remove the clutch line tube.


SST 09751-36011



CL0312

## 2. REMOVE RELEASE CYLINDER

Remove the two bolts and pull out the release cylinder.



CL0037

## DISASSEMBLY OF RELEASE CYLINDER

(See page CL-8)

### 1. PULL OUT PUSH ROD WITH BOOT

### 2. REMOVE PISTON WITH SPRING

Using compressed air, remove the piston with spring.

## INSPECTION OF RELEASE CYLINDER

HINT: Clean the disassembled parts with compressed air.

### 1. INSPECT RELEASE CYLINDER BORE FOR SCORING OR CORROSION


If a problem is found, clean or replace the cylinder.

### 2. INSPECT PISTON AND CUPS FOR WEAR, SCORING, CRACKS OR SWELLING

If either one requires replacement, use the parts from the cylinder kit.

### 3. INSPECT PUSH ROD FOR WEAR OR DAMAGE


If necessary, replace the push rod.



## ASSEMBLY OF RELEASE CYLINDER

(See page CL-8)

1. COAT PISTON WITH LITHIUM SOAP BASE GLYCOL GREASE, AS SHOWN
2. INSERT PISTON WITH SPRING INTO CYLINDER
3. INSTALL PUSH ROD WITH BOOT



## INSTALLATION OF CLUTCH RELEASE CYLINDER

(7M-GE)

1. INSTALL RELEASE CYLINDER WITH TWO BOLTS

Torque: 120 kg-cm (9 ft-lb, 12 N·m)

2. INSTALL FLEXIBLE HOSE

(a) Install and torque the flexible hose to the release cylinder.

Torque: 235 kg-cm (17 ft-lb, 23 N·m)


(b) Using SST, connect and torque the clutch line union to the flexible hose.

HINT: First, finger-tighten and then tighten to specified torque.

SST 09751-36011

Torque: 155 kg-cm (11 ft-lb, 15 N·m)

(c) Install the clip.



3. BLEED CLUTCH SYSTEM


(See page CL-4)

4. CHECK FOR LEAKS

(7M-GTE)

1. INSTALL RELEASE CYLINDER WITH TWO BOLTS

Torque: 120 kg-cmn (9 ft-lb, 12 N·m)




2. INSTALL CLUTCH LINE TUBE

Using SST, connect the clutch line tube.

HINT: First finger-tighten the union nut and then tighten it to specified torque.

SST 09751-36011

Torque: 155 kg-cm (11 ft-lb, 15 N·m)




3. BLEED CLUTCH SYSTEM

(See page CL-4)

4. CHECK FOR LEAKS

# CLUTCH UNIT COMPONENTS



## REMOVAL OF CLUTCH UNIT


### (7M-GE)


1. REMOVE TRANSMISSION  
(See page MT-4)

HINT: Do not drain the transmission oil.

2. REMOVE CLUTCH COVER AND DISC


- (a) Place the matchmarks on the clutch cover and flywheel.
- (b) Loosen each set bolt one turn at a time until spring tension is released.
- (c) Remove the set bolts and pull off the clutch cover and disc.





### 3. REMOVE RELEASE BEARING, FORK AND BOOT FROM TRANSMISSION

- (a) Remove the clips, and pull off the bearing and hub.
- (b) Remove the fork and boot.




#### (7M-GTE)

### 1. REMOVE TRANSMISSION WITH CLUTCH COVER AND DISC

(See page MT-3)

### 2. REMOVE RELEASE BEARING HUB ASSEMBLY FROM CLUTCH COVER

- (a) Using snap ring pliers, remove the snap ring.
- (b) Remove the bearing hub assembly, wave washer and plate washer.




## INSPECTION OF CLUTCH PARTS

### 1. INSPECT CLUTCH DISC FOR WEAR OR DAMAGE

Using calipers, measure the rivet head depth.

**Minimum rivet depth: 0.3 mm (0.012 in.)**

If a problem is found, replace the clutch disc.




### 2. INSPECT CLUTCH DISC RUNOUT

Using a dial indicator, check the disc runout.

**Maximum runout: 0.8 mm (0.031 in.)**

If runout is excessive, replace the disc.




### 3. INSPECT FLYWHEEL RUNOUT

Using a dial indicator, check the flywheel runout.

**Maximum runout: 0.2 mm (0.008 in.)**


If runout is excessive, replace the flywheel.



#### 4. INSPECT PILOT BEARING

Turn the bearing by hand while applying force in the axial direction.



If the bearing sticks or has much resistance, replace the pilot bearing.



#### 5. IF NECESSARY, REPLACE PILOT BEARING

(a) Using SST, remove the pilot bearing.  
SST 09303-35011

(b) Using SST, drive in a new pilot bearing.  
SST 09304-30012




#### 6. INSPECT DIAPHRAGM SPRING FOR WEAR

Using calipers, measure the diaphragm spring for depth and width of wear.

Limit: Depth 0.6 mm (0.024 in.)  
Width 5.0 mm (0.197 in.)

If necessary, replace the clutch cover.



### 7. INSPECT RELEASE BEARING

Turn the bearing by hand while applying force in the axial direction.

If the bearing sticks or has much resistance, replace the release bearing.

HINT: The bearing is permanently lubricated and requires no cleaning or lubrication.

### 8. IF NECESSARY, REPLACE RELEASE BEARING (7M-GE)



Replace release bearing assembly.

#### (7M-GTE)

- Using snap ring pliers, remove the snap ring.
- Remove the release bearing, plate washer and cone spring from the hub.
- Install the cone spring, plate washer and a new release bearing to the hub.

HINT: Make sure to install the cone spring in correct direction as shown in the figure.

- Using snap ring pliers, install the snap ring.



### 9. (7M-GTE)

#### CHECK DIAPHRAGM SPRING TIP ALIGNMENT



- Using SST, install the clutch disc on the flywheel. SST 09301-20020
- Align the matchmarks on the clutch cover and flywheel.
- Torque the bolts on the clutch cover in the order shown.

**Torque: 195 kg-cm (14 ft-lb, 19 N·m)**

HINT: Temporarily tighten the No.1 and No.2 bolts.

- Using a dial indicator and measuring point, check the diaphragm spring tip alignment.

**Maximum non-alignment: 0.5 mm (0.020 in.)**




- If non-alignment is excessive, bend the springs with SST until alignment is correct.

SST 09333-00013

- Remove the clutch cover and disc.

HINT: Loosen each set bolt one turn at a time until spring tension is released.



## INSTALLATION OF CLUTCH UNIT


(See page CL-11)

(7M-GE)

### 1. INSTALL CLUTCH DISC ON FLYWHEEL

Using SST, install the disc on the flywheel.

SST 09301-20020




### 2. INSTALL CLUTCH COVER

(a) Align the matchmarks on the clutch cover and flywheel.

(b) Torque the bolts on the clutch cover in the order shown.

**Torque: 195 kg-cm (14 ft-lb, 19 N·m)**

**HINT:** Temporarily tighten the No.1 and No.2 bolts.




### 3. CHECK DIAPHRAGM SPRING TIP ALIGNMENT

Using a dial indicator with roller instrument, check the diaphragm spring tip alignment.

**Maximum non-alignment: 0.5 mm (0.020 in.)**

If alignment is not as specified, using SST, adjust the diaphragm spring tip alignment.


SST 09333-00013





### 5. APPLY MOLYBDENUM DISULPHIDE LITHIUM BASE GREASE (NLGI NO. 2) OR MP GREASE

(a) Apply molybdenum disulphide lithium base grease to the following parts.

- Release fork and hub contact point
- Release fork and push rod contact point
- Release fork pivot point
- Clutch disc spline
- Release bearing hub inside groove



(b) Apply MP grease to the front surface of the release bearing.



**6. INSTALL BOOT, FORK AND RELEASE BEARING TO TRANSMISSION**

**7. INSTALL TRANSMISSION**  
(See page MT-6)

**(7M-GTE)**

**1. INSTALL RELEASE BEARING HUB ASSEMBLY TO CLUTCH COVER**

(a) Apply MP grease to the release bearing contact surface.

(b) Install the plate washer, wave washer and bearing hub assembly.

(c) Using a screwdriver, install the snap ring.

**HINT:** Support the release bearing under with a spacer or such to raise the bearing hub assembly.

**2. INSTALL TRANSMISSION WITH CLUTCH COVER AND DISC**

(See page MT-6)